



CANDO Diagnostic List Bendix_v5.04

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Year | System Types | Version info. | Readout DTC | History DTC | Clear DTC | Read Data stream | Actuation Test | Remark(other functions) |
|--------|--------------|---------------|-------------|-------------|-----------|------------------|----------------|---|
| Bendix | EC-17 | ✓ | ✓ | ✓ | ✓ | - | ✓ | Controller Configuration,'Rest ABS Controller |
| Bendix | EC-30 | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | Rest ABS Controller |
| Bendix | EC-60 | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | Rest ABS Controller,Dyno Mode |
| Bendix | EC-80 | ✓ | ✓ | - | ✓ | ✓ | ✓ | Reset ABS Controller |
| Bendix | TABS6 | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | Reset ABS Controller |
| Bendix | FLC20 | ✓ | ✓ | - | ✓ | ✓ | - | - |
| Bendix | MC-30 | ✓ | ✓ | - | ✓ | ✓ | ✓ | - |
| Bendix | SDP | ✓ | ✓ | - | ✓ | ✓ | - | - |
| Bendix | VS500 | ✓ | ✓ | - | ✓ | - | - | - |
| Bendix | Wingman | ✓ | ✓ | - | ✓ | - | - | - |