



CANDO Diagnostic List Nissan diesel UD_V7.43

Remark:

1. ✓ : means that the system has this function
2. - : means that the system does not have this function
3. compared with the last version, the new added function is marked in red color.

| Model | System | | | Function | | | | | Remark (other functions) |
|------------------|-------------------------|---------------|--|---------------|----------|-----------|------------------|-------------|---|
| | | | | Version info. | Read DTC | Clear DTC | Read data stream | Action test | |
| Nissan diesel UD | Nissan UD engine system | | | ✓ | ✓ | ✓ | ✓ | - | Injector nozzle data, Fuel Injection Stop Test, Running Accel Sensor Adjust, PTO Accel Sensor Adjust, Each Relay Check, EGR Check, VNT Check, Suction Air Volume Check, Fuel Check, Electric Fan Clutch |
| Nissan diesel UD | Hino Engine | | | ✓ | ✓ | ✓ | ✓ | ✓ | Protection Data; Learned value; Check functions; Manufacturer Setting Items; Customization |
| Nissan diesel UD | UD(2004~) | | | ✓ | ✓ | ✓ | ✓ | - | Injector nozzle data, Fuel Injection Stop Test, Running Accel Sensor Adjust, PTO Accel Sensor Adjust, Each Relay Check, EGR Check, VNT Check, Suction Air Volume Check, Fuel Check, Electric Fan Clutch |
| Nissan diesel UD | UD2004 and Earlier | Engine | | ✓ | ✓ | ✓ | ✓ | ✓ | - |
| Nissan diesel UD | UD2004 and Earlier | ABS | | - | ✓ | ✓ | ✓ | ✓ | - |
| Nissan diesel UD | UD2004 and Earlier | EBS | | - | ✓ | ✓ | ✓ | - | - |
| Nissan diesel UD | UD2004 and Earlier | MD9M | | ✓ | ✓ | ✓ | ✓ | ✓ | - |
| Nissan diesel UD | UD2004 and Earlier | ESCOT | | ✓ | ✓ | ✓ | ✓ | ✓ | Shift Lever Sensor Check Clutch Pedal Switch Check 1 Clutch Pedal Switch Check 2 Clutch Stroke Sensor Check 1 Clutch Stroke Sensor Check 2 |
| Nissan diesel UD | UD2004 and Earlier | SRS Airbag | | ✓ | ✓ | ✓ | ✓ | - | - |
| Nissan diesel UD | UD2004 and Earlier | AT | | ✓ | ✓ | ✓ | ✓ | - | - |
| Nissan diesel UD | UD2004 and Earlier | Smoother | | ✓ | ✓ | ✓ | ✓ | - | - |
| Nissan diesel UD | UD2004 and Earlier | HSA/CFS | | ✓ | ✓ | ✓ | - | - | Gear Shift, Select Stroke Learn, Free Clutch Torque Point Position Learn 1, Free Clutch Torque Point Position Learn 2, Start position Learn for new clutch disk |
| Nissan diesel UD | UD2004 and Earlier | BCM | | ✓ | ✓ | ✓ | ✓ | - | Hour Meter Information Clear, Fuel Data Display Clear |
| Nissan diesel UD | UD2004 and Earlier | Immobilizer | | ✓ | ✓ | ✓ | ✓ | - | - |
| Nissan diesel UD | UD2004 and Earlier | BCM(MIMAMORI) | | ✓ | ✓ | ✓ | ✓ | - | MIMAMORI All Data Clear |

